

INDUSTRIAL AIR VENT MV15 3/4"

DESCRIPTION

- ▶ The air vent are fully automatic valves, that reduce air accumulation and improves systems efficiency.
- ▶ The industrial air vents are float operated and designed to release accumulated air from high points in a piping system while the system is in operation and under pressure.
- ▶ Requires no regular maintenance.

Performance Limitations:

Maximum Design Temperature: 121°C - 250 °F
Maximum Working Pressure: @250°F -150 PSI
@150°F - 175 PSI

OPERATION

The valve, as shipped, is a normally open valve. As the system is being filled, air is vented through the small orifice. When the fluid enters the valve, the float raises and shuts off the orifice, preventing any leakage. As air accumulates and enters the valve, displacing fluid, the float drops, allowing the venting orifice to open. This cycle is repeated as often as necessary during the pumping cycle.

INSTALLATION

Industrial air vent must be installed in a vertical position at high points on a piping system. The valve's inlet must face downward. A shut-off valve should be installed below each valve in the event servicing is required. A drain line is recommended, as the valve may "spit" a small amount of fluid during venting. To vent air quickly during initial start-up, remove the ½-inch pipe plug in the cap of the air vent.

CAUTION: If TFE tape is used to form the seal on the inlet piping, keep the excess tape from entering the valve. The excess tape could interfere with proper venting or sealing of the valve.

MAINTENANCE

No regular maintenance is necessary; however, periodic inspection for leakage and function can be performed. Close the inlet service valve and slowly remove the ½ -inch pipe plug. The water level within the valve should be within 1" of the top of the opened drain plug. If not, the valve may not be functioning properly, and the valve should be removed and inspected for wear and/or possible damage from foreign matter.

For replacement parts please contact Calefactio.